


MODEL TCB1625

SPOTNAIL'S
DIVISION OF PEACE INDUSTRIES, LTD.
1100 Hicks Rd
Rolling Meadows, IL 60008
Phone : 847-259-1620



SPOTNAILS MODEL TCB1625

Ref No.	Part No.	Description
01	P-24370	Screw
02	P-96118	Bushing
03	P-70046	Exhaust Deflector
04	P-64377	O-Ring
05	P-32217	Washer
06	P-24358	Cap Screw
07	P-32211	Flat Washer
08	P-60180	Cap
◆	09	P-15193 Exhaust Seal
◆	10	P-64384 O-Ring
◆	11	P-18331 Poppet Spring
◆	12	P-64232 Poppet O-Ring
◆	13	P-63042 Poppet
◆	14	P-64422 Piston Stop O-Ring
◆	15	P-64234 Cylinder Seal O-Ring
◆	16	P-03081 Guide Spacer
◆	17	P-62079 Gasket
◆	18	P-05106 Cylinder
◆	19	P-64235 Cylinder O-Ring
◆	20	P-64423 O-Ring
◆	21	P-64424 Piston O-Ring
◆	22	P-06253 Driver Blade

Ref No.	Part No.	Description
23	AS-06073	Piston & Driver Assembly
24	P-15121	Bumper
◆	25	P-15232 Return Seal
◆	26	P-01271 Body
◆	27	P-64425 O-Ring
◆	28	P-60175 End Cap
◆	29	P-24300 Screw
◆	30	AS-10054 Front Plate Assembly
◆	31	AS-97269 Remote Valve
◆	32	P-24312 Screw
◆	33	P-99272 Mounting Plate
◆	34	P-30098 Tube Fitting
◆	35	P-99271 Feed Acuator
◆	36	P-24353 Screw
◆	37	P-32235 Washer
◆	38	P-99270 Small Feed Roller
◆	39	P-26126 Nut
◆	40	P-99273 Mounting Plate
◆	41	AS-12183 Magazine Assembly
◆	42	P-12480 Magazine Cover
◆	43	P-24307 Screw
◆	44	P-32170 Washer
◆	45	P-13042 Bracket

Ref No.	Part No.	Description
46	P-24313	Screw
47	P-99274	Mounting Plate
48	P-24317	Screw
49	P-99275	Shaft Collar
50	P-99269	Large Feed Roller
51	P-99276	Shaft Collar
52	P-99277	Tension Arm
53	P-24468	Screw
54	P-07385	Pin
55	P-18480	Spring
56	P-99282	Mounting Block
57	P-24487	Screw
58	P-99278	Cover Plate
59	P-99279	Spacer
60	P-24488	Screw
61	P-12479	Magazine
62	P-99280	Spacer
63	P-99281	Base Plate
64	AS-04036	Latch Assembly
65	P-64434	O-Ring
66	P-07353	Spiral Pin
67	P-07356	Pin

◆ Parts Included In AS-97319 O-Ring And Seal Kit