


# MODEL WS4840-W5

**SPOTNAILS**®  
DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd  
Rolling Meadows, IL 60008  
Phone : 847-259-1620  
www.spotnails.com



4/29/2013

## SPOTNAILS MODEL WS4840-W5

Ref No.	Part No.	Description
01	P-24370	Screw
02	P-96118	Bushing
03	P-70042	Exhaust Deflector
04	P-64377	O-Ring
05	P-32217	Washer
06	P-24300	Screw
07	P-32211	Flat Washer
08	P-60174	Cap
◆	09	P-15193 Exhaust Seal
◆	10	P-64384 O-Ring
◆	11	P-18331 Poppet Spring
◆	12	P-64385 Poppet O-Ring
◆	13	P-63038 Poppet
◆	14	P-64233 Piston Stop O-Ring
◆	15	P-64386 Cylinder Seal O-Ring
◆	16	P-03070 Guide Spacer
◆	17	P-62071 Gasket
◆	18	P-05097 Cylinder
◆	19	P-64387 Cylinder O-Ring
◆	20	P-64242 O-Ring
◆	21	P-64388 Piston O-Ring
◆	22	AS-06058 Piston & Driver Assembly

Ref No.	Part No.	Description
23	P-15195	Bumper
24	P-01273	Body
◆	25	P-64389 O-Ring
◆	26	P-60175 End Cap
◆	27	P-15196 Return Seal
◆	28	P-08501 Wear Plate
◆	29	P-26125 Nut
◆	30	P-24456 Screw
◆	31	P-24307 Screw
◆	32	P-24311 Screw
◆	33	P-07290 Roll Pin
◆	34	P-10326 Front Plate
◆	35	AS-99097 1/2" Robina Flooring Assy.
◆	37	P-07291 Pin
◆	38	P-53165 Safety Guide
◆	39	P-18328 Spring
◆	40	AS-53074 Safety Assembly
◆	41	P-64240 O-Ring
◆	42	P-07327 Trigger Pin
◆	43	AS-21008 Trigger Assembly
◆	44	P-15194 Valve Seal

Ref No.	Part No.	Description
45	P-18283	Spring
◆	46	P-64390 O-Ring
◆	47	P-22165 Plunger
◆	48	P-22166 Valve Housing
◆	49	P-64391 O-Ring
◆	50	P-24309 Screw
◆	51	P-12232 Track Cover
◆	52	P-18233 Spring Clip
◆	53	P-18232 Negator Spring
◆	54	P-12231 Track
◆	55	P-26124 Nut
◆	56	P-32144 Washer
◆	57	P-13081 Bracket
◆	58	P-24306 Screw
◆	59	P-03053 Spacer
◆	60	P-24310 Screw
◆	61	P-24319 Screw
◆	62	P-09149 Pusher
◆	63	P-06240 Driver Blade
◆	64	P-07363 Safety Pin
◆	65	AS-21021 Restrictive Trigger
◆	66	P-18267 Spring

◆ Parts Included In AS-97281 O-Ring And Seal Kit