

MODEL XS2640-A

SPOTNAILS


DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd

Rolling Meadows, IL 60008

Phone : 847-259-1620

SPOTNAILS MODEL XS2640-A



2015/5/6

Ref No.	Part No.	Description	Ref No.	Part No.	Description
01	P-24370	Screw	37	AS-53081	Safety Assembly
02	P-96118	Bushing	38	P-64332	Valve Housing O-Ring
03	P-70041	Exhaust Deflector	39	P-22144	Trigger Valve Cap
04	P-64377	O-Ring	40	P-64333	O-Ring
05	P-24300	Cap Screw	41	P-64334	O-Ring
06	P-32211	Flat Washer	42	P-64335	O-Ring
07	P-60172	Cap	43	P-22145	Pilot Valve
08	P-15187	Exhaust Seal	44	P-64336	O-Ring
09	P-64378	O-Ring	45	P-18227	Spring
10	P-18327	Poppet Spring	46	P-64383	Plunger O-Rings
11	P-64028	Poppet O-Ring	47	AS-22037	Plunger Assembly
12	P-63037	Poppet	49	P-64328	O-Ring
13	P-64379	Piston Stop o-Ring	50	P-64240	O-Ring
14	P-64380	Cylinder Seal O-Ring	51	P-07327	Trigger Pin
15	P-03079	Guide Spacer	52	AS-21008	Trigger Assembly
16	P-62070	Gasket	53	P-26126	Nut
17	P-64228	Piston O-Ring	54	P-24430	Screw
18	AS-06043	Piston & Driver Assembly	55	P-24432	Screw
19	P-64330	Cylinder O-Ring	56	P-12417	Magazine Cover
20	P-05096	Cylinder	57	P-07337	Negator Spring Pin
21	P-64419	O-Ring	58	P-18334	Negator Spring
22	P-15197	Bumper	59	P-13070	Bracket
23	P-01263	Body	60	P-24301	Screw
24	P-64312	O-Ring	61	P-26157	Nut Plate
25	P-60156	End Cap	62	P-24433	Screw
26	P-07262	Pin	63	P-24434	Screw
27	P-15202	Return Seal	65	P-12415	Magazine
28	P-24358	Screw	66	P-07338	Pin
29	P-10285	Stationary Front Plate	67	P-53167	Latching Safety (Optional)
30	P-07357	Pin	69	AS-97276	Filter (Optional)
31	P-10288	Removable Front Plate	70	P-53175	Roofing Safety (Optional)
32	P-18333	Latch Spring	71	AS-97296	Shingle Guide Assy (Optional)
33	P-08519	Wear Plate	73	P-09212	Pusher
34	P-04062	Quick Clear Latch	74	AS-99088	Wear Plate Filler
35	P-53165	Safety Guide	75	AS-21026	Restrictive Trigger Assy (Optional)
36	P-18328	Spring	76	P-32107	Washer
	◆	Parts Included In AS-97287 O-Ring & Seal Kit			